

measure, analyze, innovate,

Multi Sensor Set p-T

Type 6833B...

Cavity Pressure and Temperature Sensors with Multichannel Connectors, includes Mold Identification

Modular system for injection molding, multichannel applications or in multi-cavity injection molds. It consists of pressure and temperature sensors with Unisens® sensitivity for a 2- or 4-channel measurement configuration. All sensors are equipped with the single-wire technique.

- Compact for two or four pressure and temperature sensors Type 6188AAG (front ø1 mm), Type 6189AG (front ø2,5 mm) or Type 6190CAG (front ø4 mm)
- Simplified connections, using single-wire technique, designed for industrial applications
- Use of 4-channel cables for pressure and temperature sensors
- Uniform Unisens® sensitivity of all sensors
- Multichannel connector with mold identification



Description

The choice of pressure and temperature sensors with single-wire cable available for this set are the Ø1 mm Type 6188AAG, Ø2,5 mm Type 6189AG and Ø4 mm Type 6190CAG. The Set includes the 4-channel connector Type 1708A1 as well as the 2- or 4-channel temperature amplifier Type 2205A... . The two connectors, Types 1708A1 and 2205A..., are premounted on an adapter plate Type 5700A25 to avoid the need for more than one recess in the mold.

The pressure acts directly over the entire front of the sensor and is transmitted to the crystal force link, which produces a proportional electrical charge. All sensor parts are corrosion-resistant. The sensitivity (charge per pressure or pC/bar) is the same for all sensors with Unisens technology and needs to be entered only once in the process monitoring system (e.g. CoMo Injection).

The contact temperature of the plastic is measured by means of a thermocouple welded into the front of the sensor. The temperature amplifier Type 2205A... couverts the signal into a 0 ... 10 V voltage that can be passed on to an evaluation unit or process monitoring system.

The small cross-sectional area of the sensor cable allows flexibility of installation. With single-wire technology, electrical shielding is provided by the mold. The flying lead end of the cable is connected to the back of the multichannel connector using a cut and grip contact, thus dispensing with the need for a single-channel conventional connector Type 1839. The flying lead ends of the two thermocouple cables are connected on the back of the temperature amplifier.

Technical Data

Multi Sensor Set Type 6833B...

Number of channels		2	4
Mounting		in mold	in mold
Multichannel connector pressure	Туре	1708A1	1708A1
Pressure measurement	bar	0 2 000	0 2 000
Temperature amplifier	Туре	2205A121	2205A141
Temperature measurement	°C	0 200	0 200
Mounting dimensions (LxBxT)	mm	104,5x28x30	104,5x28x30
Adapter plate Type 5700A25			
(with 1708A1 and 2205A1x1)			
Extension cable (pressure)	Туре	1995A	1995A
Extension cable (temperature)	Туре	1457A1A	1457A1A
Mold temperature	°C	125	125
		125	125



Page 1/4

This information corresponds to the current state of knowledge. Kistler reserves the right to make technical changes. Liability for consequential damage resulting from the use of Kistler products is excluded.

©2012, Kistler Group, Eulachstrasse 22, 8408 Winterthur, Switzerland Tel. +41 52 224 11 11, Fax +41 52 224 14 14, info@kistler.com, www.kistler.com Kistler is a registered trademark of Kistler Holding AG.

MultSUNSTAR传感与控制and Month Mon

measure, analyze, innovate,

Application

The multi sensor set is designed for industrial use in multicavity molds. The compact premounted assembly of an adapterplate with the 4-channel connector Type 1708A1 and the temperature amplifier Type 2205A... saves space. The simplified connection technique reduces the time needed to install the multichannel extension cables Types 1995A... and 1457A... for the pressure and temperature signals.

Another very useful application is the equipping of large single or two-cavity molds, in which the pressure and temperature curve has to be measured at several locations in one cavity. The multi sensor set, with the single-wire technology and the multichannel connector, allows simple mold design for two or four sensors with central cable connections.

This simplifies and standardizes the connection to quality monitoring systems like the CoMo Injection. The hazards of a potential mix-up can be excluded when connecting the sensors to the CoMo Injection.

The measuring range and the operating temperature range are dependent on the type of basic sensor and can be taken from the corresponding data sheet.

Mounting

The sensors Types 6188AAG and 6189AG with a front diameter of 1 mm or rather front diameter of 2,5 mm is secured in the mounting bore with the spacer sleeve Type 6464A3. As the front of the sensor forms part of the cavity wall, it has to be set flush. The sensor Type 6190CAG with front diameter of ø4 mm is secured in the bore with the mounting nut Type 6457. Details of the chosen sensors are to be found in the corresponding data sheets 6188A_000-887, 6189A_000-536 and 6190CA_000-680.

The green sensor cable includes a single-wire cable for pressure signal and must be dressed into the mold and the multichannel connector must be mounted directly in the mold. The multichannel connector also has to be mounted directly in the mold to ensure electrical shielding. In order to provide adequate protection, the connector should be let into the wall of the mold (see mounting illustration Fig. 4).



4-channel connector Type 1708A1 for connection up to four Fig. 1:



2-channel or 4-channel temperature amplifier Type 2205A... Fig. 2: for connection up to four sensors

The single-wire cables of the cavity pressure sensors are tightened by hand directly into the cut-and-grip contacts behind the multichannel connector. The cable can be cut to length as appropriate for the mold dimensions.

Mold Cavity Pressure Sensors

Only single-wire sensors with Unisens sensitivity are used for the multi sensor set (i.e. a mean sensitivity with tolerance of ±2 %). The technical data along with the supplementary mounting instructions for the single-wire sensors are contained in the appropriate data sheet for the standard type of sensor. Direct mounting of the single-wire cables with the multichannel connector is a requisite for the multichannel system; this connector can then be connected via a corresponding multichannel extension cable to the CoMo Injection monitoring unit Type 2869....

For this reason, the included accessories for the multi sensor set do not contain the connector (Type 1839) or the mounting plate (Art. No. 3.520.328) listed in the data sheet for multi sensor set pT.

The Unisens sensitivity makes it easier to set up the monitoring unit. In the case of the CoMo Injection Type 2869..., the entered sensitivity can be copied from one channel to all of the others.

Processing of Measured Data

The following systems is available for automatic processing of the measured data. The relevant data sheet is:


 CoMo Injection Type 2869... for process monitoring (2869B_000-665)

Spare Parts


Sensors and cables must be ordered individually as spare parts. For sensor Type 6190CAG the spare cable of 2 m length is the Type 2219AG, the spare cable of 5 m length is the Type 2219AG1.

The cable of the sensors Types 6188AAG and 6189AG may only be replaced in the Kistler factory.

When reordering these sensors, the average sensitivity of multi sensor set p-T must be stated. The sensitivity together with the serial number is engraved on the identification plate.



Mounting for the 4-channel connector Type 1708A1 and Fig. 3: temperature amplifier Type 2205A... with adapter plate Type



Mounting dimensions for multi sensor set consisting of Type Fig. 4: 1708A1 and 2205A...



measure. analyze. innovate.

Included Accessories	Type/Art. No.	Optional Monitoring System		Туре		
 Mounting nut (for Type 6190CAG only) 	6457	• CoMo Injection 2869		2869		
 Spacer sleeve (for Types 6188AAG and 6189AG only) 	6464A3	for visualizing and monitoring the molding process, cable for connecting Type 6869A,				
 Checking tool (for Type 6188AAG only) 	3.050.241	see data sheet for Type 2869B				
 Checking tool (for Type 6189AG only) 	3.050.243	(2869B_000-665)				
• 4-channel connector for pressure signals (charge)	1708A1					
 Temperatue amplifier 2-channel for temperature signals (voltage) 	2205A121					
or						
 Temperature amplifier 4-channel 	2205A141					
for temperature signal (voltage)		Ordering Key				
Adapter plate	5700A25		Type 68331	B E		
 Cable sheath stripping tool 	1367			\uparrow \uparrow \uparrow		
 Marker set for numbering 	5.210.579	Sensor Standard Type				
of sensor cable		Type 6189AG	01			
 Identification plate with 	3.520.1093	Type 6190CAG	02			
sensor sensitivity		Type 6188AAG	03			
 Document mounting instructions 	002-405					
		Number of sensors	2			
Note		Number of sensors	4	•		
Cables, mounting nuts, spacer sleeves and checking tools are						
supplied according the number of sensors ordered.		Temperature Amplifier				

2-channels

4-channels

Each set includes one 4-channel connector Type 1708A1.

1

Optional Accessories 4-channel extension cable for Type 1708A... (max. 4 sensors) connector 6 pin pos. to connector 6 pin neg.

	1 0	
•	Length 1 m	1995A1
•	Length 2 m	1995A2
•	Length 5 m	1995A5
•	Length costumer specific	1995Asp
	$(L_{min} = 0.3 \text{ m/L}_{max} = 10 \text{ m})$	

4-channel extension cable for Type 2205A... (max. 4 sensors) Fischer connector 102 pos. to connector D-Sub 15 pin pos.

•	Length 1 m	1457A1A1
•	Length 2 m	1457A1A2
•	Length 5 m	1457A1A5
•	Length costumer specific	1457A1Asp
	$(L_{min} = 0.3 \text{ m/L}_{max} = 30 \text{ m})$	

• Mounting tool for connecting the temperature cable to Type 2205A...

Extraction tools

for Types 6188AAG and 6189AG 1358A for Type 6190CAG 1315A

• Tubular socket wrench (only for Type 6190CAG)

Page 4/4

This information corresponds to the current state of knowledge. Kistler reserves the right to make technical changes. Liability for consequential damage resulting from the use of Kistler products is excluded.

©2012, Kistler Group, Eulachstrasse 22, 8408 Winterthur, Switzerland Tel. +41 52 224 11 11, Fax +41 52 224 14 14, info@kistler.com, www.kistler.com Kistler is a registered trademark of Kistler Holding AG.